

Instructions for Use

Hot plate table top 30-100°C

continuously heated

separately heated (2 zones)

Model-No.	Art.-No.	Model-No.	Art.-No.
26060/4	C 0100	26080/4/G	C 1102
:	:	:	:
26150/8	C 0149	26150/8/G	C 1149



Scholl Apparatebau GmbH & Co. KG

Zinhainer Weg 4
D-56470 Bad Marienberg/Germany

Phone +0049 (0) 2661 – 9868-10
 Fax +0049 (0) 2661 – 9868-38 (Service)
 Internet www.scholl-gastro.de
 E-mail info@scholl-gastro.de



Hot plate table top 30-100°C continuously heated

Model-No.	Art.-No.	Art.-No.	Art.-No.	Art.-No.	Art.-No.
D (mm)	400	500	600	700	800
26060/-	C 0100	C 0110	C 0120	C 0130	C 0140
26070/-	C 0101	C 0111	C 0121	C 0131	C 0141
26080/-	C 0102	C 0112	C 0122	C 0132	C 0142
26090/-	C 0103	C 0113	C 0123	C 0133	C 0143
26100/-	C 0104	C 0114	C 0124	C 0134	C 0144
26110/-	C 0105	C 0115	C 0125	C 0135	C 0145
26120/-	C 0106	C 0116	C 0126	C 0136	C 0146
26130/-	C 0107	C 0117	C 0127	C 0137	C 0147
26140/-	C 0108	C 0118	C 0128	C 0138	C 0148
26150/-	C 0109	C 0119	C 0129	C 0139	C 0149

Hot plate table top 30-100°C separately heated (2 zones)

Model-No.	Art.-No.	Art.-No.	Art.-No.	Art.-No.	Art.-No.
D (mm)	400	500	600	700	800
26060/-/G		C 1110	C 1120	C 1130	C 1140
26070/-/G		C 1111	C 1121	C 1131	C 1141
26080/-/G	C 1102	C 1112	C 1122	C 1132	C 1142
26090/-/G	C 1103	C 1113	C 1123	C 1133	C 1143
26100/-/G	C 1104	C 1114	C 1124	C 1134	C 1144
26110/-/G	C 1105	C 1115	C 1125	C 1135	C 1145
26120/-/G	C 1106	C 1116	C 1126	C 1136	C 1146
26130/-/G	C 1107	C 1117	C 1127	C 1137	C 1147
26140/-/G	C 1108	C 1118	C 1128	C 1138	C 1148
26150/-/G	C 1109	C 1119	C 1129	C 1139	C 1149



TABLE OF CONTENTS

Table of contents.....	3
Preface.....	5
1 Conventions.....	6
1.1 Pictograms – General safety notes	6
1.2 Pictograms – Warning notes	8
1.3 Pictograms – Important notes	9
2 Product information	10
2.1 Information regarding compliance with standards, laws and directives	10
2.2 Safety	10
3 Packing, transport, intermediate storage, scope of delivery	11
3.1 Packing.....	11
3.2 Transport.....	11
3.3 Intermediate storage	11
3.4 Scope of delivery.....	11
4 Installation and electrical installation	12
4.1 Installation	12
4.2 Electrical installation.....	12
5 Operation	13
5.1 Intended use	13
5.2 Unintended use.....	14
6 Maintenance	15
6.1 Maintenance and repair	15
6.2 Cleaning and care.....	15
7 Troubleshooting	17
7.1 Possible malfunctions	18
8 Technical data.....	19



8.1	Execution	19
8.2	Dimensioned drawings	20
8.3	Circuit diagrams	20
8.4	Spare parts list	21
9	Disposal and Environmental Notes	22
9.1	Disposal of packing material	22
9.2	Disposal of the appliance	22
10	Warranty and service	23
10.1	Warranty conditions	23
10.2	Service	23
10.3	Service address	24

PREFACE

Congratulations!

In purchasing this new SCHOLL appliance you have chosen a product which meets highest technical standards while providing outstanding convenience in practical use.

This appliance has been designed with minimal energy consumption in mind. Used responsibly, it will serve you well in an ecologically sound manner.

Please read the information in this manual carefully before starting up this appliance. On the following pages you will find important notes regarding its operation, care and maintenance so that you will be able to enjoy its use for a long time.

If a malfunction should nevertheless occur, please consult the "Troubleshooting" section first. In many cases you should be able to remedy minor problems yourself, thus saving unnecessary service costs.

Please retain this manual carefully and pass it on to any subsequent user for his or her information and safety.

A quality product, properly treated, will give you many years of satisfactory service.

We trust you will enjoy using this product!









Yours sincerely




Gustav Scholl Apparatebau GmbH & Co. KG








1 CONVENTIONS

1.1 PICTOGRAMS – GENERAL SAFETY NOTES








	<p>Be sure to observe these Instructions for Use as well as the safety notes to prevent injuries or damage to health or property. Do not alter or modify this appliance.</p>
	<p>Never use a defective appliance. If you suspect the unit of being faulty or discover an unusual noise or smell, turn off the power switch and pull the plug out of the socket-outlet, or otherwise disconnect the appliance from the mains and de-energize it (i.e., ensure that it no longer carries any voltage). Do not use this appliance when its power cord is damaged.</p> <p>Failure to observe this warning may result in a fire hazard or electrical shock!</p>
	<p>Maintenance and repair work must be carried out only by qualified professionals using original spare parts and accessories. Do not attempt to carry out repairs on this appliance yourself!</p>
	<p>Connect this appliance to suitably earthed mains outlets only. Ensure that your mains power supply conforms to the data stated on the nameplate of the appliance.</p> <p>Failure to observe this warning may result in a fire hazard or electrical shock!</p>
	<p>Place this appliance on a sturdy, level and heat-resistant surface to prevent fire hazards and accidents.</p>
	<p>This appliance is not intended to be used by persons (including children) of limited physical, sensory or intellectual abilities, or lacking in experience and/or knowledge, unless they are supervised by a person responsible for safety who instructs them in the use of the device. Children should be supervised to ensure they will not play with this appliance.</p>
	<p>Do not run the power cord near heat sources, over sharp edges, etc. Always pull on the plug, not the cord, to remove it from a socket-outlet since the cord might be damaged as a result. Do not allow cords to hang unsupported. Route the cord so that it will not form a tripping hazard!</p>
	<p>When using an extension cord, unwind the cord from the reel to prevent heat build-up or cord fires, respectively. The socket-and-plug connection must be splash-proof and be made of, or coated with, rubber. Each wire must have a cross-section of at least 1.5 mm².</p>

	<p>Do not allow this appliance to operate unattended. Ensure that its thermostat switch is set to "0" before inserting the plug into an electrical socket-outlet or connecting the appliance to the power supply. Avoid starting the unit unintentionally. Connecting the unit to the mains with its thermostat switch not set to "0" may cause accidents.</p>
	<p>Protect this appliance from moisture (water spray, rain). Do not immerse the appliance in water or other fluids and do not place it in a dishwasher. Any penetration of water into the unit will increase the risk of an electrical shock.</p>
	<p>Do not touch the surfaces of the appliance. The surfaces of this appliance may get hot. Please allow the unit to cool down fully before cleaning or stowing it. Never cover this appliance.</p> <p>Burn injury or fire hazard!</p>

1.2 PICTOGRAMS – WARNING NOTES

	<p>Before any cleaning, maintenance or repair work is carried out, the appliance must be disconnected from the mains and de-energized. To do so, it is not enough to set the power switch to OFF. Instead, the mains plug must be pulled or the electrical circuit must be de-energized, respectively. Check that no voltage is present before opening the appliance, and lock out the circuit to make it safe against re-energizing.</p>
	<p>Cleaning must only be performed by qualified persons who have read and understood these Instructions for Use and are familiar with applicable hygiene rules. Ensure that care is exercised during cleaning of the unit.</p> <p>Cleaning of stainless steel</p> <p>For light cleaning, wipe down the surface with a cloth or soft brush/sponge soaked in warm water which contains a small amount of dishwashing detergent. Follow this up by wiping with clear water until no cleaning agent residue remains on the surface, as the latter might cause discoloration or stains. Finish by rubbing the surface dry.</p> <p>To remove more stubborn or extensive residue, a stainless steel cleaning product may be used.</p> <p>Never use any of the following for cleaning:</p> <ul style="list-style-type: none"> ➤ aggressive or bleaching products, i.e., containing active oxygen, chlorine, or caustic/corrosive constituents. ➤ abrasive cleaning products such as scouring creams/pastes, steel wool, saponified steel wool, metal or plastic sponges, or sponges with a scratchy surface (scouring side).
	<p>Never use steam and/or pressure jet cleaning equipment to clean this appliance!</p> <p>This might damage the appliance to the point where it may pose a hazard to your life!</p>
	<p>The total permitted regeneration and hot-holding time according to HACCP will be exceeded after 3 hours.</p> <p>Risk of potential health impairment!</p>
	<p>Allow the unit to cool down before starting any cleaning work.</p> <p>Burn hazard!</p>

1.3 PICTOGRAMS – IMPORTANT NOTES

	<p>DANGER</p> <p>indicates an immediately threatening hazard.</p> <p>Failure to observe this warning notice will result in severe physical injury or death.</p>
	<p>WARNING</p> <p>indicates a potentially dangerous situation.</p> <p>Failure to observe this warning notice may result in severe physical injury or death.</p>
	<p>CAUTION</p> <p>indicates a potentially harmful situation.</p> <p>Failure to observe this notice may result in damage to property.</p>
	<p>DANGER – electrical voltage</p> <p>indicates an immediately threatening hazard.</p> <p>Failure to observe this warning notice will result in severe physical injury or death.</p>
	<p>CAUTION! IMPORTANT</p> <p>Improper use may result in minor injuries or damage to property.</p>
	<p>In addition to these Instructions for Use, a number of accident prevention and other regulations apply with regard to the operation of this appliance. As regards food handling, please observe HACCP rules concerning compliance with hygiene requirements.</p> <p>If you have any questions, please contact your supervisor(s) or safety representative.</p>
	<p>This product must not be disposed of in domestic waste.</p> <p>Please arrange for proper recycling of this product via your local provider of waste disposal services.</p>

2 PRODUCT INFORMATION


Hot plates are electrically heated and are used for keeping the preheated food and baked goods on output temperature. Hot plates are feeded from above using appropriate dishes.

2.1 INFORMATION REGARDING COMPLIANCE WITH STANDARDS, LAWS AND DIRECTIVES

This appliance conforms to the following:

Standards, laws, directives	
2014/35/EU	Low Voltage Directive
2014/30/EU	EMC Directive

2.2 SAFETY

	<p>This appliance conforms to accepted technical rules and relevant safety codes. However, proper use of the appliance is a prerequisite for effectively preventing damage or accidents. Please comply with the notes provided in these Instructions for Use.</p>
---	---

Further safety notes, refer to section

- 1.1 Pictograms – General safety notes
- 1.2 Pictograms – Warning notes
- 1.3 Pictograms – Important notes

3 PACKING, TRANSPORT, INTERMEDIATE STORAGE, SCOPE OF DELIVERY

3.1 PACKING

The type of packing employed will depend, to a large extent, on the adopted shipping mode and route. Except where otherwise agreed by contract, packing will conform to the "HPE Packing Guideline" defined by the German Federal Association of the Wooden Materials, Pallets and Export Packing Industry and by the German Engineering Federation.

3.2 TRANSPORT

Particular care must be exercised during shipping and handling of this appliance to prevent damage resulting from exposure to excessive force or careless loading/unloading.

Shocks during shipping and handling must be avoided.

The appliance itself must be handled with care.

3.3 INTERMEDIATE STORAGE

Appliances not to be installed immediately upon delivery must be carefully stored in a protected place. For the duration of such storage they must be properly covered to prevent any ingress of dust and moisture into the unit.

3.4 SCOPE OF DELIVERY

The content of the delivery is stated in the delivery note and must be checked for completeness upon receipt.

Any damage in transit and/or missing items must be reported in writing immediately.



4 INSTALLATION AND ELECTRICAL INSTALLATION

4.1 INSTALLATION

Before the installation of the appliance, observe the following:

- Inspect the unit for any defect or damage sustained in transit.
- Check all screw connections for tightness.
- Familiarize yourself with the Instructions for Use and with the conditions for the safe operation of this appliance.
- Clean the unit before the first use according to chapter "Cleaning and care".
- Place the unit at a suitable location.

4.2 ELECTRICAL INSTALLATION

	<p>The appliance may only be installed by a qualified electrician whilst taking into account the applicable regulations!</p>
	<p>Connect this appliance to suitably earthed mains outlets only. Ensure that your mains power supply conforms to the data stated on the nameplate of the appliance.</p> <p>Failure to observe this warning may result in a fire hazard or electrical shock!</p>

Before putting the appliance into service, observe the following:



- **Faulty equipment must not be taken into operation!**
- Legal requirements and the connection conditions of your local power supply company must be fully observed.
- Electrical safety functions must be carried out and checked for operability.
- This device is protection class I, the mains connection line has a protective conductor.
- This device is equipped with a mains connection line with plug.
This device must be set up so that the plug is freely accessible; otherwise, an on-site upstream separating device (e.g. switch with at least 3 mm contact opening width) must be installed to ensure complete disconnection from the mains.

5 OPERATION

The hot plate has a thermostat and an indicator lamp.

The thermostat switches the hot plate on and off and sets the temperature.


Hot plates with 2 separate heated zones have 2 thermostats and 2 indicator lamps.

	<p>Thermostat off Position "0" (Number "0" is below the mark)</p> <p>Thermostat on Position "1" to "10" (Number "1" to "10" is below the mark)</p>
	<p>indicator lamp lit Heating on</p> <p>indicator lamp dark Heating off</p>

5.1 INTENDED USE

Practice:

- Turn the thermostat to the maximum temperature (position "10").
 - The heating time of the hot plate is approx. 45 minutes.
 - After the heating time, the device is ready for operation and can be equipped with the foods to be kept warm.
 - The food must be preheated and must **not** be deep-frozen!
 - Please use suitable crockery for best heat performance.
- Set the thermostat to the desired temperature.
- For switching off after use of the hot plate:
 - Turn the thermostat to the left in the position "0". The signal lamp goes out.
 - Let the hot plate cool off.

	<p>Do not touch the device surfaces. The surfaces of the device may grow hot. Please let the device cool off entirely before cleaning it. Do not cover the device.</p> <p>Danger of burns and fire!</p>
---	--





5.2 UNINTENDED USE

Please observe strictly:




- Hot plates are **not** for defrosting/warming up of deep-frozen/cooled food.
- Hot plates are **not** for cooking food.

6 MAINTENANCE



6.1 MAINTENANCE AND REPAIR

	<p>Maintenance and repairs on the appliance must only be carried out by an authorized professional observing applicable safety regulations.</p> <p>Improperly executed work will put your safety at risk!</p>
	<p>Before any cleaning, maintenance or repair work is carried out, the appliance must be disconnected from the mains and de-energized. To do so, it is not enough to set the power switch to OFF. Instead, the mains plug must be pulled or the electrical circuit must be de-energized, respectively. Check that no voltage is present before opening the appliance, and lock out the circuit to make it safe against re-energizing.</p>


6.2 CLEANING AND CARE

	<p>Before any cleaning, maintenance or repair work is carried out, the appliance must be disconnected from the mains and de-energized. To do so, it is not enough to set the power switch to OFF. Instead, the mains plug must be pulled or the electrical circuit must be de-energized, respectively. Check that no voltage is present before opening the appliance, and lock out the circuit to make it safe against re-energizing.</p>
	<p>Never use steam and/or pressure jet cleaning equipment to clean this appliance!</p> <p>This might damage the appliance to the point where it may pose a hazard to your life!</p>
	<ul style="list-style-type: none"> ➤ Allow the unit to cool down before cleaning it. Burn hazard! ➤ Stainless steel is particularly susceptible to scratching! ➤ Remove lime, grease and starch residue immediately to avoid the formation of stains. ➤ When using a cleaning product, observe the instructions for use provided by its manufacturer.






	<p>Cleaning must only be performed by qualified persons who have read and understood these Instructions for Use and are familiar with applicable hygiene rules. Ensure that care is exercised during cleaning of the unit.</p> <p>Cleaning of stainless steel</p> <p>For light cleaning, wipe down the surface with a cloth or soft brush/sponge soaked in warm water which contains a small amount of dishwashing detergent. Follow this up by wiping with clear water until no cleaning agent residue remains on the surface, as the latter might cause discoloration or stains. Finish by rubbing the surface dry.</p> <p>To remove more stubborn or extensive residue, a stainless steel cleaning product may be used.</p> <p>Never use any of the following for cleaning:</p> <ul style="list-style-type: none"> ➤ aggressive or bleaching products, i.e., containing active oxygen, chlorine, or caustic/corrosive constituents. ➤ abrasive cleaning products such as scouring creams/pastes, steel wool, saponified steel wool, metal or plastic sponges, or sponges with a scratchy surface (scouring side).
	<p>We recommend you to clean the stainless steel surface once per week using a standard commercial stainless steel care product. This will result in the formation of a protective layer which prevents discoloration of the stainless steel surface.</p> <p>In any event, observe the product manufacturer's instructions and try each product in a small area first before applying it to a larger surface.</p>

7 TROUBLESHOOTING

	<p>Repairs must be carried out by an authorized specialist in compliance with applicable safety codes and regulations.</p> <p>Improperly executed work will put your safety at risk!</p>
---	---

Note that some work must only be carried out by an electrical specialist. According to DIN EN 60204-1: 2011-01, specialists are "persons who by reason of their relevant training and experience are capable of recognizing risks and avoiding potential hazards."

Some malfunctions you may be able to remedy yourself. Always check first if the problem is due to an operating error. Repairs are not free of charge, even within the warranty period, if the problem is caused by an operating error or if you have failed to observe any of the following instructions.

	<p>Before any cleaning, maintenance or repair work is carried out, the appliance must be disconnected from the mains and de-energized. To do so, it is not enough to set the power switch to OFF. Instead, the mains plug must be pulled or the electrical circuit must be de-energized, respectively. Check that no voltage is present before opening the appliance, and lock out the circuit to make it safe against re-energizing.</p>
	<p>Work at the electrical installation must only be performed by qualified electricians!</p>
	<p>Maintenance and repair work must be carried out only by qualified professionals using original spare parts and accessories. Do not attempt to carry out repairs on this appliance yourself!</p>

7.1 POSSIBLE MALFUNCTIONS

Malfunction	Cause	Remedy
Hot plate does not heat	Defective plug/electrical cord	<p>DANGER! Hazardous electrical voltage. Pull out the mains plug and bar product from further use.</p> <p>To be remedied by an electrical specialist.</p>
Hot plate does not heat	Thermostat faulty	Exchange thermostat
Hot plate does not heat	Heating faulty	Exchange heating



8 TECHNICAL DATA

8.1 EXECUTION

- Chrome nickel steel 18/10
- Continuously adjustable temperature from 30°C - 100°C by thermostat
- With control lamp
- Voltage 230 V~, power 500-2000 W
- connecting cable approx. 1,7m long, with right angle plug
- 115 mm total height

Hot plate table top 30-100°C continuously heated																					
Model	Length	Art.-No.	D = 400 mm		Art.-No.		D = 500 mm		Art.-No.		D = 600 mm		Art.-No.		D = 700 mm		Art.-No.		D = 800 mm		
26060/-	600 mm	C 0100	1 x	500 W	C 0110	1 x	630 W	C 0120	1 x	630 W	C 0130	1 x	750 W	C 0140	1 x	750 W					
26070/-	700 mm	C 0101	1 x	630 W	C 0111	1 x	630 W	C 0121	1 x	750 W	C 0131	1 x	1000 W K	C 0141	1 x	1000 W K					
26080/-	800 mm	C 0102	1 x	630 W	C 0112	1 x	750 W	C 0122	1 x	1000 W K	C 0132	2 x	630 W	C 0142	2 x	630 W					
26090/-	900 mm	C 0103	1 x	750 W	C 0113	1 x	750 W	C 0123	1 x	1000 W K	C 0133	1 x	1000 W K	C 0143	2 x	630 W					
26100/-	1.000 mm	C 0104	1 x	750 W	C 0114	1 x	1000 W K	C 0124	1 x	875 W	C 0134	2 x	750 W	C 0144	2 x	750 W					
26110/-	1.100 mm	C 0105	1 x	1000 W K	C 0115	1 x	1000 W K	C 0125	1 x	1000 W L	C 0135	2 x	750 W	C 0145	2 x	1000 W K					
26120/-	1.200 mm	C 0106	1 x	1000 W K	C 0116	1 x	1000 W L	C 0126	1 x	1000 W L	C 0136	2 x	750 W	C 0146	2 x	1000 W K					
26130/-	1.300 mm	C 0107	1 x	1000 W K	C 0117	1 x	1000 W L	C 0127	1 x	1000 W L	C 0137	2 x	875 W	C 0147	2 x	875 W					
26140/-	1.400 mm	C 0108	1 x	1000 W L	C 0118	1 x	1000 W K	C 0128	2 x	750 W	C 0138	2 x	875 W	C 0148	2 x	875 W					
26150/-	1.500 mm	C 0109	1 x	1000 W L	C 0119	1 x	1000 W L	C 0129	2 x	750 W	C 0139	2 x	1000 W L	C 0149	2 x	1000 W L					

Hot plate table top 30-100°C separately heated (2 zones)																					
Model	Length	Art.-No.	D = 400 mm		Art.-No.		D = 500 mm		Art.-No.		D = 600 mm		Art.-No.		D = 700 mm		Art.-No.		D = 800 mm		
26060/-/G	600 mm				C 1110	2 x	330 W	C 1120	2 x	500 W	C 1130	2 x	630 W	C 1140	2 x	630 W					
26070/-/G	700 mm				C 1111	2 x	400 W	C 1121	2 x	400 W	C 1131	2 x	630 W	C 1141	2 x	750 W					
26080/-/G	800 mm	C 1102	2 x	330 W	C 1112	2 x	400 W	C 1122	2 x	630 W	C 1132	2 x	630 W	C 1142	2 x	750 W					
26090/-/G	900 mm	C 1103	2 x	400 W	C 1113	2 x	400 W	C 1123	2 x	630 W	C 1133	2 x	630 W	C 1143	2 x	750 W					
26100/-/G	1.000 mm	C 1104	2 x	400 W	C 1114	2 x	630 W	C 1124	2 x	630 W	C 1134	2 x	630 W	C 1144	2 x	750 W					
26110/-/G	1.100 mm	C 1105	2 x	400 W	C 1115	2 x	630 W	C 1125	2 x	630 W	C 1135	2 x	750 W	C 1145	2 x	750 W					
26120/-/G	1.200 mm	C 1106	2 x	400 W	C 1116	2 x	630 W	C 1126	2 x	750 W	C 1136	2 x	750 W	C 1146	2 x	1000 W K					
26130/-/G	1.300 mm	C 1107	2 x	630 W	C 1117	2 x	630 W	C 1127	2 x	750 W	C 1137	2 x	750 W	C 1147	2 x	1000 W K					
26140/-/G	1.400 mm	C 1108	2 x	630 W	C 1118	2 x	630 W	C 1128	2 x	750 W	C 1138	2 x	1000 W K	C 1148	4 x	630 W					
26150/-/G	1.500 mm	C 1109	2 x	750 W	C 1119	2 x	750 W	C 1129	2 x	750 W	C 1139	2 x	1000 W K	C 1149	4 x	630 W					

K = kurz = short

L = lang = long



8.2 DIMENSIONED DRAWINGS

Dimensioned drawings are available upon request.



The information in the dimensioned drawings always take precedence over the summary of the technical data in chapter 8.1.

8.3 CIRCUIT DIAGRAMS

Circuit diagrams are available upon request.





8.4 SPARE PARTS LIST

	<p>Maintenance and repairs on the appliance must only be carried out by an authorized professional observing applicable safety regulations.</p> <p>Improperly executed work will put your safety at risk!</p>
	<p>Work at the electrical installation must only be performed by qualified electricians!</p>

Art.-No.	Components
70,10,02	thermostat 30-110°C
70,20,05	thermostat-toggle 0-10
73,10,04	signallamp-holder round, untill July 2008
73,10,05	Glowlamp, untill July 2008
73,10,07	blind transparent yellow round, untill July 2008
73,10,19	Signallamp from July 2008
73,30,10	terminal block 3-pole porcelain
73,30,55	connection clip 2-pole porcelain 1127G
73,30,91	wire clip 4-pole porcelain
73,70,30	connecting cable H05RN-F 3G1 with right angle plug
73,80,75	single core 260° transparent
73,80,83	single core BIAF 1,5 green/yellow
74,70,06	appliance 120-15-21, black
71,20,01	heating 330 W
70,10,02	heating 400 W
71,20,02	heating 500 W, 230V, U-shape
71,10,03	heating 630 W
71,10,04	heating 750 W
71,10,05	heating 875 W
71,10,06	heating 1000 W, short
71,10,09	heating 1000 W, long

9 DISPOSAL AND ENVIRONMENTAL NOTES

	<p>The appliance has been packed before shipping to protect it against damage in transit. After unpacking, please dispose of packing materials in an environmentally sound manner.</p> <p>All packing materials are eco-compatible, 100% recyclable and marked with a symbol to that effect.</p>
	<p>While unpacking, keep packing materials (polyethylene bags, pieces of polystyrene, etc.) out of the reach of children.</p>

9.1 DISPOSAL OF PACKING MATERIAL

Recyclable packing materials should be disposed of in sorted fractions for recycling via approved local disposal facilities.

For approved disposal facilities in your area, please contact your local government or community administration.

9.2 DISPOSAL OF THE APPLIANCE

Render the appliance inoperable before disposal.

Pull the plug out of the socket-outlet or arrange for disconnection by an electrician, then cut the mains cord off the appliance.

This product must not be disposed of in normal household waste at the end of its service life, but must be turned in for recycling at an approved collecting facility. This requirement is identified by a symbol on the product, in the Instructions for Use, or on the packing material.

Materials are recyclable as marked. By arranging for the recycling, recovery, or other form of re-use of end-of-life appliances you will make an important contribution to the protection of our environment.

Your local government or community administration will advise you as to which disposal facilities in your area accept discarded appliances for recycling.

10 WARRANTY AND SERVICE

10.1 WARRANTY CONDITIONS

The manufacturer accepts no liability or warranty in the following cases:

- failure to observe notes and instructions given in the Instructions for Use;
- use of the product in a manner not conforming to its intended use;
- alteration or modification of the appliance or its functionalities;
- use of non-original spare parts.

Except as otherwise stipulated by special warranty conditions, a 12-month warranty is granted on all product vis-a-vis merchants (details are covered by para. 11 of our General Terms and Conditions of Sale).

The warranty granted on appliances is a material warranty valid for a 1-year period, i.e., if a defect should occur we will send you the relevant part. The defective part must be returned to our address within two weeks. No claim based on alleged unsoundness of goods or for consequential loss or damage involving factors unrelated to the appliance will be accepted. Further warranty information is contained in our General Terms and Conditions of Sale or can be made available upon request.

Appliances not produced by ourselves are subject to the warranty terms and conditions or the relevant manufacturer. These, too, will normally be limited to a material warranty. We do not grant any direct warranty on such items.

10.2 SERVICE



IMPORTANT

To enable our customer service to prepare repairs carefully and to provide the appropriate spare parts, please provide the following information when reporting a customer service requirement:

1. Your precise address (where applicable, final customer's address, person to contact)
2. Your contact details such as phone, fax and e-mail (including, where applicable, those of the final customer)
3. Times when a customer service visit will be convenient
4. Exact appliance specifications (consult the nameplate and/or purchase receipt)
5. Purchase date
6. Accurate description of the problem or of your service request (including, where applicable, a photo of the defect or installation situation)

Please also keep the purchase receipt on hand. This will help us avoid unnecessary time and costs while enabling us to work more efficiently for you.



10.3 SERVICE ADDRESS

You can reach us at the following times:

Monday - Thursday from 7:00 a.m. till 4:00 p.m.

Fridays from 7:00 a.m. till 12:15 p.m.

Outside these office hours please communicate your requests per e-mail or telefax.

Scholl Apparatebau GmbH & Co. KG

Zinhainer Weg 4

D-56470 Bad Marienberg/Germany

Phone 0049 (0)2661/9868-10

Telefax 0049 (0)2661/9868-38

E-mail support@scholl-gastro.de

